

## Category - Alphabetical

SoundName	MSB-LSB-PRG	Category
Accordion + Clarinet *	093-000-028	Accordion
Accordion + Trumpet *	093-000-026	Accordion
Accordion + Zither *	093-000-027	Accordion
Accordion 16 *	090-000-059	Accordion
Accordion 2x8Ch *	090-000-038	Accordion
Accordion 3Ch *	090-000-022	Accordion
Accordion 8 *	090-000-058	Accordion
Accordion Mixed 1 *	090-000-037	Accordion
Accordion Mixed 2 *	093-000-025	Accordion
Bandoneon 1 *	090-000-024	Accordion
Bandoneon 2 *	090-000-060	Accordion
Bandoneon 3 *	090-000-061	Accordion
Blues Harp Distorted	082-000-061	Accordion
CD-Accordion *	091-000-007	Accordion
CD-Accordion St *	091-000-008	Accordion
Diatonisch + Bandoneon *	093-000-031	Accordion
Diatonisch 1 *	090-000-021	Accordion
Diatonisch 2 *	090-000-062	Accordion
Diatonisch 3 *	093-000-023	Accordion
Diatonisch Chorus *	093-000-030	Accordion
Diatonisch Echo *	093-000-024	Accordion
Diatonisch Mixed *	093-000-029	Accordion
German Accordion	082-000-056	Accordion
GM022 Accordion *	089-000-021	Accordion
GM024 Tango Accordion *	089-000-023	Accordion
Musette 1 *	090-000-023	Accordion
Musette 2 *	090-000-064	Accordion
Musette Accordion	082-000-060	Accordion
Parisian	082-000-059	Accordion
Russian Accordion	082-000-057	Accordion
Tango Accordion	082-000-058	Accordion
Tango Accordion *	090-000-053	Accordion
Acoustic Bass	084-000-032	Bass
Acoustic Bass 1 *	090-000-034	Bass
Acoustic Bass 1 P *	091-000-126	Bass
Acoustic Bass 2 *	090-000-093	Bass
Acoustic Bass 2 P *	090-000-094	Bass
Bass Guitar *	090-000-033	Bass
Bass Slide	082-000-070	Bass
Bass Sweep	082-000-071	Bass
Brass Bass *	093-000-055	Bass
Bright Fat Acoustic Bass	082-000-062	Bass
CD-Zupfbass * (plucked)	091-000-005	Bass
CD-Zupfbass Ped * (plucked)	091-000-006	Bass
Contrabass Ensemble	093-000-094	Bass
Disco Bass	084-000-034	Bass
Fat Acoustic Bass	082-000-062	Bass
Finger Bass	084-000-030	Bass
Finger Bass Ped *	093-000-000	Bass
Finger Jazz Bass	082-000-066	Bass
Finger P Bass	082-000-067	Bass
FM Bass	082-000-075	Bass
Fretless Bass	082-000-069	Bass

Category - Alphabetical

Fretless Bass	084-000-033	Bass
GM033 Acoustic Bass *	089-000-032	Bass
GM034 Finger Bass *	089-000-033	Bass
GM035 Picked Bass *	089-000-034	Bass
GM036 Fretless Bass *	089-000-035	Bass
GM037 Slap Bass 1 *	089-000-036	Bass
GM038 Slap Bass 2 *	089-000-037	Bass
GM039 Synth Bass 1 *	089-000-038	Bass
GM040 Synth Bass 2 *	089-000-039	Bass
GM044 Contrabass *	089-000-043	Bass
GM088 Bass + Lead *	089-000-087	Bass
Pedal Bass 1 *	090-000-035	Bass
Pedal Bass 2 *	090-000-063	Bass
Pedal Sustain Long 1	095-000-096	Bass
Pedal Sustain Long 2	095-000-097	Bass
Pedalbass+Orchestra	093-000-063	Bass
Pedalbass+Sinus	093-000-065	Bass
Pedalbass+Strings 1	093-000-061	Bass
Pedalbass+Strings 2	093-000-062	Bass
Pedalbass+Timpani	093-000-060	Bass
Pedalbass+Tuba	093-000-064	Bass
Pick Bass 1	082-000-064	Bass
Pick Bass 2	082-000-065	Bass
Picked Bass	084-000-031	Bass
Picked Bass Pedal *	093-000-001	Bass
Punchy Acoustic Bass	082-000-063	Bass
SH Bass	082-000-073	Bass
Slap Bass	082-000-068	Bass
Slap Bass	084-000-035	Bass
Sub Metal Arpeggio	083-000-096	Bass
Synth Bass	084-000-036	Bass
Synth Bass Ped *	093-000-002	Bass
Thumb Bass	082-000-072	Bass
Ultraog Bass	072-000-012	Bass
Big Band Brass 1 *	091-000-080	Brass
Big Band Brass 2 *	091-000-081	Brass
Big Band Brass 3 *	090-000-107	Brass
Big Band Brass Soft *	090-000-108	Brass
Brass Orchestra *	091-000-114	Brass
Brass Section	084-000-075	Brass
Brass Section *	090-000-014	Brass
Brass Sforzando *	090-000-103	Brass
Brassy Orchestra	082-000-099	Brass
Fanfare 1 *	091-000-117	Brass
Fanfare 2 *	091-000-118	Brass
Flugelhorn *	090-000-045	Brass
French Horn Section	082-000-084	Brass
GM057 Trumpet *	089-000-056	Brass
GM058 Trombone *	089-000-057	Brass
GM059 Tuba *	089-000-058	Brass
GM060 Muted Trumpet *	089-000-059	Brass
GM061 French Horn *	089-000-060	Brass
GM062 Brass Section *	089-000-061	Brass
Horn Section *	090-000-097	Brass

Category - Alphabetical

Horn Section Swell *	090-000-098	Brass
Horn Section Warm *	090-000-099	Brass
Horn Solo *	090-000-100	Brass
Horns + Strings *	091-000-111	Brass
Hybrid Stabs	082-000-082	Brass
Jazz Guitar / Brass *	093-000-039	Brass
Jazz Trombone *	091-000-076	Brass
Jazz Trumpet *	091-000-074	Brass
Muted Trumpet	082-000-036	Brass
Muted Trumpet / Brass *	093-000-038	Brass
Real Brass Section 1 T	082-000-078	Brass
Real Brass Section 2	082-000-079	Brass
Saxophone / Brass 16' *	093-000-032	Brass
Saxophone / Brass 8' *	093-000-033	Brass
Small Brass *	091-000-047	Brass
Small Brass Section L	082-000-080	Brass
Small Trombone	082-000-039	Brass
Small Trumpet	082-000-034	Brass
Soft Solo Trumpet	082-000-033	Brass
Soft Trombone	082-000-038	Brass
Solo Trumpet	082-000-032	Brass
Solo Trumpet *	091-000-075	Brass
Solo Trumpet 2	093-000-098	Brass
Soul Section Loose PG	082-000-081	Brass
Trombone	082-000-037	Brass
Trombone *	090-000-013	Brass
Trombone 1	084-000-072	Brass
Trombone 2	084-000-073	Brass
Trombone Ens *	090-000-105	Brass
Trombone Ensemble	084-000-074	Brass
Trombone Soft *	090-000-052	Brass
Trumpet *	090-000-012	Brass
Trumpet Bright *	090-000-054	Brass
Trumpet Echo *	091-000-119	Brass
Trumpet Ensemble	093-000-095	Brass
Trumpet Ensemble *	090-000-106	Brass
Trumpet Filter *	091-000-120	Brass
Trumpet Live	093-000-088	Brass
Trumpet Mariachi	093-000-087	Brass
Trumpet Muted *	090-000-055	Brass
Trumpet Ping-Pong *	093-000-041	Brass
Tuba	082-000-040	Brass
Ultimate Brass Section	082-000-077	Brass
Applause *	093-000-003	Effect
Auto Car	083-000-087	Effect
Bird *	093-000-004	Effect
Birds	083-000-082	Effect
Brass Down Up *	093-000-043	Effect
Breath Noise *	093-000-005	Effect
CD-Drops *	091-000-014	Effect
Dentist's Kick	083-000-080	Effect
Effect Allg. +C5	093-000-110	Effect
Effect Latin +C5	093-000-111	Effect
Effect Others +C5	093-000-115	Effect

Category - Alphabetical

Effect Sacral +C5	093-000-114	Effect
Effect Timpani +C5	093-000-117	Effect
Effect Trad +C5	093-000-112	Effect
Effect Vocal +C5	093-000-116	Effect
Effect Western +C5	093-000-113	Effect
GM Seashore *	075-000-005	Effect
GM123 Seashore *	089-000-122	Effect
GM124 Bird Tweet *	089-000-123	Effect
GM125 Telephone *	089-000-124	Effect
GM126 Helicopter *	089-000-125	Effect
GM127 Applause *	089-000-126	Effect
GM128 Gunshot *	089-000-127	Effect
Gunshot *	093-000-007	Effect
Helicopter *	093-000-008	Effect
Large Applause	083-000-084	Effect
Large Crowd Laugh	083-000-086	Effect
Phone *	093-000-009	Effect
SciFi LFO FX	083-000-081	Effect
Seashore 1*	075-000-006	Effect
Seashore 2*	093-000-010	Effect
Small Applause	083-000-083	Effect
Small Crowd Laugh	083-000-085	Effect
Trumpet Alarm *	093-000-042	Effect
Vocals Effects *	093-000-011	Effect
Wind Atmosphere	083-000-075	Effect
Yeah Yeah Frog	083-000-079	Effect
B3 2nd Chorus	095-000-026	El Organ
B3 2nd Vib/Rot	095-000-027	El Organ
B3 3rd Rotor	095-000-024	El Organ
B3 Born 2 Late	096-000-015	El Organ
B3 Dark Cel	095-000-013	El Organ
B3 Dark Chorus	095-000-014	El Organ
B3 Guitar Cele	095-000-025	El Organ
B3 Jazz 2nd Cel	095-000-023	El Organ
B3 Jazz 2nd Rotor	095-000-022	El Organ
B3 Medium Norm	095-000-016	El Organ
B3 Open Cel	095-000-015	El Organ
B3 Open Rotor	095-000-002	El Organ
B3 Open Rot-Vib	095-000-003	El Organ
B3 Rotor Pedal 1	095-000-010	El Organ
B3 Rotor Pedal 2	095-000-011	El Organ
B3 Rotor UM 1	095-000-007	El Organ
B3 Rotor UM 2	095-000-008	El Organ
B3 Rotor UM 3	095-000-009	El Organ
B3 Soft Rot-Vib	095-000-004	El Organ
B3 Straight Rotor	095-000-001	El Organ
B3 Straight Vib	095-000-012	El Organ
B3 Sus + Perc Vib	095-000-091	El Organ
B3 Sustain Rotor	095-000-088	El Organ
B3 Sustain UM	095-000-093	El Organ
B3 Sustain Vib	095-000-089	El Organ
B3 Tutti Rotor	095-000-005	El Organ
B3 Vibrato Pedal 1	095-000-020	El Organ
B3 Vibrato Pedal 2	095-000-021	El Organ

Category - Alphabetical

B3 Vibrato UM 1	095-000-017	El Organ
B3 Vibrato UM 2	095-000-018	El Organ
B3 Vibrato UM3	095-000-019	El Organ
B4 100 Pound Berta	020-000-049	El Organ
B4 12 O'Clock Drive	020-000-065	El Organ
B4 16' + 1'	020-000-076	El Organ
B4 16' 8' 4' 2' 1'	020-000-078	El Organ
B4 2nd Perc	020-000-061	El Organ
B4 2nd Perc Vib	020-000-062	El Organ
B4 3rd Perc	020-000-064	El Organ
B4 3rd Perc Vib	020-000-063	El Organ
B4 5th Organ	020-000-025	El Organ
B4 60s Beat	020-000-085	El Organ
B4 60s Vibrato	020-000-084	El Organ
B4 91 Wheels	020-000-030	El Organ
B4 A Whiter Shade	020-000-012	El Organ
B4 Acid Scan	020-000-051	El Organ
B4 America	020-000-032	El Organ
B4 Ballsy	020-000-057	El Organ
B4 Blues	020-000-000	El Organ
B4 Born to B4	020-000-016	El Organ
B4 Brake On!	020-000-034	El Organ
B4 Brasses	020-000-011	El Organ
B4 Brian's Choice	020-000-018	El Organ
B4 Can't Stand the Rain	020-000-023	El Organ
B4 Champ	020-000-056	El Organ
B4 Clarinet / Vibraharp	020-000-099	El Organ
B4 Clean 70s	020-000-077	El Organ
B4 Deep Scanner	020-000-007	El Organ
B4 Diapason / Full Great	020-000-115	El Organ
B4 Distortion	020-000-005	El Organ
B4 Dulciana / Flute + Str	020-000-110	El Organ
B4 Emerson's Basic	020-000-014	El Organ
B4 Entertainer A	020-000-081	El Organ
B4 Entertainer B	020-000-082	El Organ
B4 Entertainer C	020-000-083	El Organ
B4 Exceptional	020-000-080	El Organ
B4 Flute / Cello	020-000-109	El Organ
B4 Flute 16' 8'	020-000-071	El Organ
B4 Flutes / Great no Reed	020-000-113	El Organ
B4 French Horn / Cello	020-000-097	El Organ
B4 French Horn / Clarinet	020-000-111	El Organ
B4 Full B3 Clean	020-000-072	El Organ
B4 Full Brass / Bombarde	020-000-105	El Organ
B4 Full Rock	020-000-087	El Organ
B4 Full Swell / Full Great	020-000-106	El Organ
B4 Full Swell / Full Great	020-000-117	El Organ
B4 Full Swell /Diapason +	020-000-118	El Organ
B4 Full Tibias / Bombarde	020-000-107	El Organ
B4 Full Tibias 16' / Accordion	020-000-103	El Organ
B4 Fuzz Guitar	020-000-031	El Organ
B4 Fuzzzzzzzzz	020-000-035	El Organ
B4 Gimme Some	020-000-089	El Organ
B4 Gospel	020-000-094	El Organ

Category - Alphabetical

B4 Green Onions	020-000-017	El Organ
B4 Hollow	020-000-033	El Organ
B4 Holmes	020-000-052	El Organ
B4 House Base	020-000-036	El Organ
B4 House Base 2	020-000-037	El Organ
B4 House Bright	020-000-045	El Organ
B4 House Church	020-000-046	El Organ
B4 House Full Bar	020-000-039	El Organ
B4 House Organ Dry	020-000-092	El Organ
B4 House Perc Rotator	020-000-042	El Organ
B4 House Perc Vibrato	020-000-043	El Organ
B4 House Plop	020-000-040	El Organ
B4 House Rotator	020-000-041	El Organ
B4 House Scanner	020-000-038	El Organ
B4 House Vibrato Drive	020-000-044	El Organ
B4 House Vibrato Lux	020-000-047	El Organ
B4 Hush	020-000-026	El Organ
B4 Initial	020-000-120	El Organ
B4 J. B. Percussion	020-000-010	El Organ
B4 Jazz 2nd Percussion	020-000-053	El Organ
B4 Jazzy 1	020-000-075	El Organ
B4 Jazzy 2	020-000-093	El Organ
B4 Jimmy	020-000-095	El Organ
B4 Jimmy McG	020-000-058	El Organ
B4 Keyclicker	020-000-008	El Organ
B4 Kraut Rock	020-000-027	El Organ
B4 Latin 66'	020-000-002	El Organ
B4 Lord 1	020-000-019	El Organ
B4 Lower Chorus	020-000-059	El Organ
B4 McDuff	020-000-055	El Organ
B4 Novel Solo / Vox + Tibia	020-000-100	El Organ
B4 Oboe / Open Diapason	020-000-114	El Organ
B4 Oboe / Open Diapason	020-000-119	El Organ
B4 Oboe Horn / Diapason	020-000-102	El Organ
B4 Overdriven 2nd Perc	020-000-066	El Organ
B4 Overdriven 2nd Perc Vibrato	020-000-068	El Organ
B4 Overdriven 3rd Perc	020-000-067	El Organ
B4 Overdriven 3rd Perc Vibrato	020-000-069	El Organ
B4 Percussive Organ	020-000-074	El Organ
B4 Percy	020-000-086	El Organ
B4 Progressive	020-000-006	El Organ
B4 Purple	020-000-088	El Organ
B4 Raindrops	020-000-054	El Organ
B4 Rock Ballad	020-000-090	El Organ
B4 Rockers HiFi	020-000-024	El Organ
B4 Salicional / Diapason +	020-000-112	El Organ
B4 Samba Pa Ti	020-000-020	El Organ
B4 Scanner Full Bar	020-000-001	El Organ
B4 Screamin' B4	020-000-028	El Organ
B4 Seasons of the Witches	020-000-022	El Organ
B4 Small Faces	020-000-021	El Organ
B4 Smiley	020-000-079	El Organ
B4 Soft Backing	020-000-073	El Organ
B4 Soft Organ	020-000-003	El Organ

Category - Alphabetical

B4 Soft Rock	020-000-091	El Organ
B4 Stopped Flute / Gamba	020-000-108	El Organ
B4 Super Perc	020-000-029	El Organ
B4 The Base	020-000-060	El Organ
B4 The Cat	020-000-015	El Organ
B4 The Worm	020-000-048	El Organ
B4 Theatre Organ	020-000-004	El Organ
B4 Theatre Solo / String	020-000-101	El Organ
B4 Tibias 8' + 2' / Dulciana	020-000-098	El Organ
B4 Time of Seasons	020-000-013	El Organ
B4 Trumpet / Tibia Clausa	020-000-104	El Organ
B4 Trumpet / Tibia Clausa	020-000-116	El Organ
B4 Upper Chorus	020-000-050	El Organ
B4 Velocity	020-000-009	El Organ
B4 Vibrator!	020-000-070	El Organ
B4 Vox / Strings	020-000-096	El Organ
CD-Jazz Organ *	091-000-001	El Organ
CD-Jazz Organ St *	091-000-002	El Organ
DB 16 1-1/3 1	093-000-070	El Organ
DB 16 8 4 2	093-000-068	El Organ
DB 16 8 4 2 1	093-000-069	El Organ
DB Blues 1	093-000-071	El Organ
DB Blues 1 Perc	093-000-073	El Organ
DB Blues 2 Perc	093-000-074	El Organ
DB Blues 2	093-000-072	El Organ
DB Full 1	093-000-066	El Organ
DB Full 2	093-000-067	El Organ
DB Lower 1	093-000-075	El Organ
DB Lower 2	093-000-076	El Organ
DB Straight Rotor	074-000-001	El Organ
DB Straight Rotor	074-000-010	El Organ
Draw Perc 3rd	084-000-102	El Organ
Drawbars Perc 3rd	074-000-002	El Organ
GM017 Organ *	089-000-016	El Organ
GM018 Perc. Organ *	089-000-017	El Organ
GM019 Rock Organ *	089-000-018	El Organ
H100 Straight Rotor	095-000-006	El Organ
H100 Vibrato 1	096-000-011	El Organ
Helios 2nd Chorus	095-000-051	El Organ
Helios 2nd Rotor	095-000-049	El Organ
Helios 3rd Vibrato	095-000-050	El Organ
Helios Bell Jazz	096-000-006	El Organ
Helios Dark Celeste	095-000-038	El Organ
Helios Dark Chorus	095-000-039	El Organ
Helios Full Rotor + Vibrato	096-000-002	El Organ
Helios Jimmy Smith	096-000-007	El Organ
Helios Medium Norm	095-000-041	El Organ
Helios Mixed Full Rotor + Vib	096-000-004	El Organ
Helios Open Celeste	095-000-040	El Organ
Helios Open Rotor	095-000-029	El Organ
Helios Open Rotor/Vib	095-000-030	El Organ
Helios Perc Guitar	095-000-048	El Organ
Helios Rotor Pedal 1	095-000-035	El Organ
Helios Rotor Pedal 2	095-000-036	El Organ

Category - Alphabetical

Helios Rotor UM 1	095-000-032	El Organ
Helios Rotor UM 2	095-000-033	El Organ
Helios Rotor UM 3	095-000-034	El Organ
Helios Silky Drawbar	096-000-008	El Organ
Helios Straight Rotor	095-000-028	El Organ
Helios Straight Vibrato	095-000-037	El Organ
Helios Sustain UM	095-000-094	El Organ
Helios Sustain Vibrato	095-000-090	El Organ
Helios Tutti Rotor	095-000-031	El Organ
Helios Vibrato LM 3	095-000-044	El Organ
Helios Vibrato Pedal 1	095-000-045	El Organ
Helios Vibrato Pedal 2	095-000-046	El Organ
Helios Vibrato UM 1	095-000-042	El Organ
Helios Vibrato UM 2	095-000-043	El Organ
LM Alt Helios	096-000-010	El Organ
LM Warm Helios	096-000-009	El Organ
Organ	084-000-104	El Organ
Organ *	093-000-044	El Organ
Organ Drawbars 1	095-000-000	El Organ
Organ Drawbars 2	095-000-106	El Organ
Perc Organ	084-000-103	El Organ
Perc Organ *	093-000-045	El Organ
Rock Organ	074-000-009	El Organ
Rock Organ	084-000-101	El Organ
Rock Organ *	093-000-046	El Organ
Scanner C1	074-000-006	El Organ
Scanner C2	074-000-007	El Organ
Scanner C3	074-000-008	El Organ
Scanner V1	074-000-003	El Organ
Scanner V2	074-000-004	El Organ
Scanner V3	074-000-005	El Organ
Spectra 2nd Perc	095-000-071	El Organ
Spectra 2nd Rotor	095-000-074	El Organ
Spectra 3rd Vib	095-000-075	El Organ
Spectra Bell Jazz	096-000-005	El Organ
Spectra Dark Celeste	095-000-062	El Organ
Spectra Dark Chorus	095-000-063	El Organ
Spectra Full Rotor + Vibrato	096-000-001	El Organ
Spectra Medium Vibrato	095-000-065	El Organ
Spectra Mixed Full Rotor + Vib	096-000-003	El Organ
Spectra Open Celeste	095-000-064	El Organ
Spectra Open Rotor	095-000-053	El Organ
Spectra Open Rotor + Vibrato	095-000-054	El Organ
Spectra Perc Guitar	095-000-073	El Organ
Spectra Perc User	095-000-072	El Organ
Spectra Rotor Pedal 1	095-000-059	El Organ
Spectra Rotor Pedal 2	095-000-060	El Organ
Spectra Rotor UM 1	095-000-056	El Organ
Spectra Rotor UM 2	095-000-057	El Organ
Spectra Rotor UM 3	095-000-058	El Organ
Spectra Straight Rotor	095-000-052	El Organ
Spectra Straight Vibrato	095-000-061	El Organ
Spectra Sus + Perc	095-000-092	El Organ
Spectra Sustained UM	095-000-095	El Organ



Category - Alphabetical

Spectra Tutti Rotor	095-000-055	El Organ
Spectra Vibrato Ped 1	095-000-069	El Organ
Spectra Vibrato Ped 2	095-000-070	El Organ
Spectra Vibrato UM 1	095-000-066	El Organ
Spectra Vibrato UM 2	095-000-067	El Organ
Spectra Vibrato UM 3	095-000-068	El Organ
TestSound	095-000-127	El Organ
GM105 Sitar *	089-000-104	Ethnic
GM107 Shamisen *	089-000-106	Ethnic
GM108 Koto *	089-000-107	Ethnic
Sitar *	091-000-061	Ethnic
GM106 Banjo *	089-000-105	Guitar
1 Finger Plucker - 1	082-000-004	Guitar
1 Finger Plucker - 2	082-000-005	Guitar
12 String *	090-000-081	Guitar
12 String Atmos Pad	082-000-013	Guitar
12 String Steel *	091-000-084	Guitar
12 String Washy	082-000-010	Guitar
24 String Guitar	082-000-011	Guitar
Atmospheric Lead + Pad	082-000-031	Guitar
Banjo	084-000-027	Guitar
Banjo *	091-000-062	Guitar
CD-Jazz Guitar *	091-000-003	Guitar
Clean Guitar	084-000-029	Guitar
Clean Guitar *	090-000-119	Guitar
Comet Guitar *	091-000-023	Guitar
Distortion Guitar	084-000-025	Guitar
Distortion Guitar *	090-000-121	Guitar
E-Guitar Ricky	093-000-093	Guitar
FM Jazz Guitar	082-000-023	Guitar
GM025 Nylon Guitar *	089-000-024	Guitar
GM026 Steel Guitar *	089-000-025	Guitar
GM027 Jazz Guitar *	089-000-026	Guitar
GM028 Electric Guitar *	089-000-027	Guitar
GM029 Muted Guitar *	089-000-028	Guitar
GM030 Overdriven Guitar *	089-000-029	Guitar
GM031 Distortion Guitar *	089-000-030	Guitar
GM032 Harmonics Guitar *	089-000-031	Guitar
GM121 Guitar Fret Noise *	089-000-120	Guitar
Guitar Fretless *	093-000-006	Guitar
Hackbrett *	090-000-044	Guitar
Hawaiian Guitar *	090-000-046	Guitar
Jazz Guitar	084-000-024	Guitar
Jazz Guitar *	090-000-005	Guitar
Jazz-Guitar Django	093-000-090	Guitar
Lead Guitar	082-000-028	Guitar
Lead Guitar Licks	082-000-030	Guitar
Lead Guitar Wah	082-000-029	Guitar
Muted Guitar	084-000-023	Guitar
Muted Guitar *	090-000-118	Guitar
Natural Guitar *	090-000-004	Guitar
Natural Guitar 2 *	090-000-079	Guitar
Natural Guitar Slide	093-000-099	Guitar
Nu Metal Stack	082-000-027	Guitar

Category - Alphabetical

Nylon + Steel Hybrid	082-000-009	Guitar
Nylon Finger & Harmonics	082-000-001	Guitar
Nylon Finger Acoustic Bright	082-000-003	Guitar
Nylon Finger Acoustic Guitar	082-000-000	Guitar
Nylon Pick	082-000-005	Guitar
Nylon String + 1	084-000-020	Guitar
Nylon+Harmonic+Hammer	082-000-002	Guitar
Nylon+Harmonics+Hammer	082-000-006	Guitar
Overdriven Guitar *	090-000-120	Guitar
Pedal Steel Guitar	093-000-100	Guitar
Pedal Steel Slide Guitar	093-000-101	Guitar
Solid Clean	084-000-021	Guitar
Solid Wah Wah	084-000-026	Guitar
St String+Harmonics	082-000-008	Guitar
Steel Guitar *	091-000-083	Guitar
Steel String + 1	084-000-019	Guitar
Steel String Guitar	082-000-007	Guitar
Steel+Body	084-000-028	Guitar
SteelString + AtmoPad	082-000-012	Guitar
Strat Chorus	082-000-016	Guitar
Strat Clean	082-000-014	Guitar
Strat Glam	082-000-024	Guitar
Strat Grunge	082-000-026	Guitar
Strat Harmonics	082-000-019	Guitar
Strat Jimmy Riff	082-000-025	Guitar
Strat Muted Velo	082-000-020	Guitar
Strat Muted Wah	082-000-021	Guitar
Strat Tremolo	082-000-018	Guitar
Strat Wah	082-000-017	Guitar
Strat+Harmonics+Hammers	082-000-015	Guitar
Stratocaster *	090-000-078	Guitar
Stratocaster + 1	084-000-018	Guitar
Stratocaster without Vib	093-000-097	Guitar
Western Guitar *	090-000-080	Guitar
Western Guitar 2 *	093-000-058	Guitar
Zither 1 *	090-000-025	Guitar
Zither 2 *	090-000-084	Guitar
GM047 Harp *	089-000-046	Harp
Harp *	090-000-124	Harp
Mandolin 1 *	090-000-082	Mandolin
12String Guitar	084-000-022	OAA
12StringGtr Acc	084-000-007	OAA
AcousticBass Acc	084-000-014	OAA
Brass Acc	084-000-002	OAA
CleanGuitar Acc	084-000-011	OAA
DistortionGtr Acc	084-000-013	OAA
ElectricBass Acc	084-000-015	OAA
FretlessBass Acc	084-000-017	OAA
HiStringGtr Acc	084-000-008	OAA
Large Strings Acc	084-000-001	OAA
NylonGuitar Acc	084-000-005	OAA
OverdriveGtr Acc	084-000-012	OAA
PickBass Acc	084-000-016	OAA
Small Strings Acc	084-000-000	OAA

Category - Alphabetical

SolidGuitar1 Acc	084-000-009	OAA
SolidGuitar2 Acc	084-000-010	OAA
SteelGuitar Acc	084-000-006	OAA
TenorSax Acc	084-000-004	OAA
Trumpet Acc	084-000-003	OAA
Bagpipe *	091-000-066	Other
Big Orchestra Hit	081-000-081	Other
Bright Orchestra	082-000-099	Other
GM023 Harmonica *	089-000-022	Other
GM056 Orchestra Hit *	089-000-055	Other
GM110 Bag Pipe *	089-000-109	Other
GM112 Shanai *	089-000-111	Other
GM122 Breath Noise *	089-000-121	Other
Harmonica *	090-000-026	Other
Jazz Split 1 *	093-000-035	Other
Jazz Split 2 *	093-000-036	Other
Jazz Split 3 *	093-000-037	Other
Long Orchestra Hit	081-000-082	Other
Mandolin Orchestra 1 *	090-000-083	Other
Marimba Repeat	093-000-102	Other
Mouth Organ Blues	093-000-078	Other
Orchestra *	090-000-040	Other
Orchestral Hit *	091-000-026	Other
Rondo Orchestra *	091-000-113	Other
Shanai *	091-000-068	Other
Vollenweider *	091-000-085	Other
(06 Acousticdrums 1 XG)	094-000-005	Percussion
(06 Acousticdrums 2 XG)	094-000-006	Percussion
(11 Disco 1 XG)	094-000-010	Percussion
(11 Disco 2 XG)	094-000-011	Percussion
(31 Dance 2 XG)	094-000-030	Percussion
01 Standard 1 XG	094-000-000	Percussion
02 Standard 2 XG	094-000-001	Percussion
03 Standard GM	094-000-002	Percussion
04 Traditional XG	094-000-003	Percussion
05 Standard 3 XG	094-000-004	Percussion
09 Room XG	094-000-008	Percussion
10 Room GM	094-000-009	Percussion
13 Power Kit 1	094-000-012	Percussion
14 Power Kit 2	094-000-013	Percussion
15 Standard Kit 1	940-000-014	Percussion
16 Standard Kit 2	094-000-015	Percussion
17 Rock 1 XG	094-000-016	Percussion
18 Power GM	094-000-017	Percussion
19 Rock 2 XG	094-000-018	Percussion
20 Rock 3 XG	094-000-019	Percussion
22 Techno 1 XG	094-000-021	Percussion
23 Techno 2 XG	094-000-022	Percussion
24 Techno 3 XG	094-000-023	Percussion
25 Electro XG	094-000-024	Percussion
26 Analog XG	094-000-025	Percussion
27 Dance XG	094-000-026	Percussion
28 Electro GM	094-000-027	Percussion
29 Analog GM	094-000-028	Percussion

Category - Alphabetical

30 Dance GM	094-000-029	Percussion
32 Studio Kit	094-000-031	Percussion
33 Jazz XG	094-000-032	Percussion
34 Jazz GM	094-000-033	Percussion
35 Jazz Kit	094-000-034	Percussion
36 Brush Kit	094-000-035	Percussion
37 Hit Kit	094-000-036	Percussion
38 Room Kit	094-000-037	Percussion
39 Electro Kit	094-000-039	Percussion
39 Rock Kit	094-000-038	Percussion
41 Brush Kit XG	094-000-040	Percussion
42 Brush GM	094-000-041	Percussion
44 Analog Kit	094-000-043	Percussion
45 Dance Kit	094-000-044	Percussion
46 Pop Latin Kit	094-000-045	Percussion
47 Arabic Kit	094-000-046	Percussion
48 Cuban Kit	094-000-047	Percussion
49 Orchestra XG	094-000-048	Percussion
50 Orchestra GM	094-000-049	Percussion
63 Effekte	0940-000-062	Percussion
All Bellz	081-000-057	Percussion
Bass Marimba	081-000-052	Percussion
Big Timpani	081-000-086	Percussion
Bright Steeldrums	081-000-056	Percussion
Chime Bells	081-000-066	Percussion
Chimey Tubular Bells	081-000-060	Percussion
GG-Marimba *	091-000-022	Percussion
Glockenspiel *	090-000-009	Percussion
GM010 Glockenspiel *	089-000-009	Percussion
GM011 Music Box *	089-000-010	Percussion
GM012 Vibraphone *	089-000-011	Percussion
GM013 Marimba *	089-000-012	Percussion
GM014 Xylophone *	089-000-013	Percussion
GM015 Tubular Bells *	089-000-014	Percussion
GM048 Timpani *	089-000-047	Percussion
GM113 Tinkle Bell *	089-000-112	Percussion
GM114 Agogo *	089-000-113	Percussion
GM115 Steel Drums *	089-000-114	Percussion
GM116 Woodblock *	089-000-115	Percussion
GM117 Taiko Drums *	089-000-116	Percussion
GM118 Melodic Tom *	089-000-117	Percussion
GM119 Synth Drum *	089-000-118	Percussion
GM120 Reverse Cymbal *	089-000-119	Percussion
Hard Tubular Bells	081-000-059	Percussion
Hold Bell Layer	081-000-062	Percussion
Marimba	081-000-051	Percussion
Marimba *	090-000-115	Percussion
Medium Timpani	081-000-087	Percussion
Melody Bells	081-000-061	Percussion
Music Box *	090-000-114	Percussion
Octave Xylophone	081-000-054	Percussion
Orchestral Perc	081-000-088	Percussion
Pretty Bells	081-000-065	Percussion
Rich Stereo Vibes	081-000-050	Percussion

Category - Alphabetical

Simple Tubular Bells	081-000-058	Percussion
Soft Chimey Bells	081-000-067	Percussion
Squeaker Loop	083-000-093	Percussion
Standard 1 XG	094-000-000	Percussion
Timpani *	090-000-032	Percussion
Tinker Bells	081-000-064	Percussion
Tubular Bells *	090-000-116	Percussion
Vibes Tremolo	093-000-056	Percussion
Viborbellz Cascade	081-000-068	Percussion
Vibraphon 2 *	090-000-065	Percussion
Vibraphone 1 *	090-000-001	Percussion
Warm Vibraphone	081-000-049	Percussion
Wheel Adjust Bell	081-000-063	Percussion
Xylophon *	090-000-056	Percussion
Xylophone	081-000-053	Percussion
Amped Wurli	081-000-031	Piano
Atmospheric Piano	081-000-005	Piano
Belly	081-000-040	Piano
Bright Grand Piano	081-000-001	Piano
Bright Grand Piano *	090-000-109	Piano
Bright Harmonic Steeldrums	081-000-056	Piano
California Grand	081-000-016	Piano
Caribic *	091-000-082	Piano
CD-Cembalo *	091-000-012	Piano
Celesta *	090-000-010	Piano
Chorus Clav	081-000-043	Piano
Classic Piano	093-000-089	Piano
Clavinet	081-000-041	Piano
Clavinet *	090-000-113	Piano
Clavinet Stereo *	091-000-097	Piano
Concert Hall Grand Piano	081-000-004	Piano
Dyno Chorus	081-000-035	Piano
Dyno Stage	081-000-033	Piano
Electrhodes	081-000-023	Piano
Electric Grand 1 *	090-000-111	Piano
Electric Grand 2 *	091-000-072	Piano
Electric Grand Atmosphere	081-000-012	Piano
Electric Grand Piano	081-000-010	Piano
E-Piano 1 *	090-000-003	Piano
E-Piano 2 *	091-000-098	Piano
E-Piano 3 *	091-000-099	Piano
E-Piano Bells *	091-000-101	Piano
E-Piano Pad *	091-000-100	Piano
Fantasy Rhodes *	091-000-095	Piano
FM Electric Piano	081-000-036	Piano
Full Wurli	081-000-028	Piano
Fusion	081-000-027	Piano
Gentle Vintage EP	081-000-021	Piano
GM001 Acoustic Grand *	089-000-000	Piano
GM002 Bright Grand *	089-000-001	Piano
GM003 Electric Grand *	089-000-002	Piano
GM004 Honky Tonk *	089-000-003	Piano
GM005 E-Piano 1 *	089-000-004	Piano
GM006 E-Piano 2 *	089-000-005	Piano

Category - Alphabetical

GM007 Harpsichord *	089-000-006	Piano
GM008 Clavinet *	089-000-007	Piano
GM009 Celesta *	089-000-008	Piano
GM016 Dulcimer *	089-000-015	Piano
Grand Piano	084-000-105	Piano
Grand Piano *	090-000-000	Piano
Hard Grand Piano	081-000-003	Piano
Harpsichord	081-000-045	Piano
Harpsichord *	090-000-112	Piano
Harpsichord + Octave	081-000-046	Piano
Heaven Piano	081-000-017	Piano
Hi Piano Resonance	081-000-013	Piano
Honky Tonk Piano	081-000-008	Piano
Honkytonk *	090-000-110	Piano
House Piano	081-000-006	Piano
Hybrid Stage Piano	081-000-032	Piano
Kalimba *	091-000-065	Piano
Koto *	091-000-064	Piano
LA Piano Hard	081-000-015	Piano
LA Piano Soft	081-000-014	Piano
Metal Tyne	081-000-039	Piano
Nastichord	081-000-047	Piano
Natural Grand Piano	081-000-000	Piano
Nice Tyne	081-000-038	Piano
Ol Upright Piano	081-000-007	Piano
Paddy Roads	081-000-024	Piano
Phaser Piano	081-000-009	Piano
Phaserichord	081-000-048	Piano
Piano + Strings *	091-000-091	Piano
Piano + Vocals *	091-000-073	Piano
Piano Octave *	091-000-071	Piano
Rhodes 1 *	090-000-002	Piano
Rhodes 2 *	091-000-093	Piano
Rhodes 3 *	091-000-094	Piano
Smooth Steeldrums	081-000-055	Piano
Soft Electric Grand	081-000-011	Piano
Soft Grand Piano	081-000-002	Piano
Soft Vintage EP	081-000-022	Piano
Spectral EP	081-000-019	Piano
Steel Drums *	091-000-070	Piano
Steele Hammer Piano	081-000-018	Piano
Stereo Clavinet	081-000-042	Piano
Sweet EP	081-000-037	Piano
Synth Wurli	081-000-034	Piano
Tinkle Bell *	091-000-069	Piano
Ultra Hard Vintage EP	081-000-025	Piano
Vintage Amped EP	081-000-026	Piano
Vintage Electric Piano	081-000-020	Piano
Vintage Road + Wurli	081-000-030	Piano
Wah Clav	081-000-044	Piano
Wurli Soft	081-000-029	Piano
GM020 Church Organ *	089-000-019	Pipe Organ
GM021 Reed Organ *	089-000-020	Pipe Organ
Reed Organ *	090-000-117	Pipe Organ

Category - Alphabetical

Sacral db Flutes	095-000-076	Pipe Organ
Sacral db Mezzo	095-000-077	Pipe Organ
Sacral db Ped 1	095-000-084	Pipe Organ
Sacral db Ped 2	095-000-085	Pipe Organ
Sacral db Ped 3	095-000-086	Pipe Organ
Sacral db Ped 4	095-000-087	Pipe Organ
Sacral db Plenum	095-000-078	Pipe Organ
Sacral db Tutti	095-000-079	Pipe Organ
Sacral db UM 1	095-000-080	Pipe Organ
Sacral db UM 2	095-000-081	Pipe Organ
Sacral db UM 3	095-000-082	Pipe Organ
Sacral db UM 4	095-000-083	Pipe Organ
Sacral Mixed 1 *	093-000-047	Pipe Organ
Sacral Mixed 2 *	093-000-048	Pipe Organ
Sacral Mixed 3 *	093-000-049	Pipe Organ
Sacral Mixed Vocal *	093-000-051	Pipe Organ
Sacral Principal *	090-000-048	Pipe Organ
Sacral Rohrfloete *	090-000-049	Pipe Organ
Sacral Tutti 1 *	090-000-047	Pipe Organ
Sacral Tutti 2 *	093-000-052	Pipe Organ
Sacral Tutti Vocal *	093-000-050	Pipe Organ
Theatre db OM 1	095-000-098	Pipe Organ
Theatre db OM 2	095-000-099	Pipe Organ
Theatre db OM 3	095-000-100	Pipe Organ
Theatre db OM 4	095-000-101	Pipe Organ
Theatre db OM 5	095-000-102	Pipe Organ
Theatre db UM 1	095-000-103	Pipe Organ
Theatre db UM 2	095-000-104	Pipe Organ
Theatre db UM 3	095-000-105	Pipe Organ
Theatre Diaphone *	090-000-074	Pipe Organ
Theatre Drums *	090-000-075	Pipe Organ
Theatre Kinura *	090-000-073	Pipe Organ
Theatre Organ *	090-000-069	Pipe Organ
Theatre String *	090-000-070	Pipe Organ
Theatre String Sustain *	093-000-054	Pipe Organ
Theatre Sustain *	090-000-072	Pipe Organ
Theatre Tibia 8' *	090-000-068	Pipe Organ
Alt Sax F	084-000-066	Saxophone
Alt Sax Section	084-000-071	Saxophone
Alto Sax	082-000-042	Saxophone
Alto Sax F *	090-000-077	Saxophone
Alto Sax Medium	093-000-059	Saxophone
Alto Sax MF *	090-000-016	Saxophone
Alto Sax Section *	091-000-125	Saxophone
Bariton Sax*	091-000-028	Saxophone
Baritone Sax	082-000-043	Saxophone
Brighter Section Loose	082-000-046	Saxophone
Brighter Section Tight	082-000-047	Saxophone
GM065 Soprano Sax *	089-000-064	Saxophone
GM066 Alto Sax *	089-000-065	Saxophone
GM067 Tenor Sax *	089-000-066	Saxophone
GM068 Baritone Sax *	089-000-067	Saxophone
Miller Sax	084-000-069	Saxophone
Miller Sax *	090-000-104	Saxophone

Category - Alphabetical

Rock Sax *	091-000-122	Saxophone
Sax Section 1	084-000-067	Saxophone
Sax Section 1 *	090-000-071	Saxophone
Sax Section 2	084-000-068	Saxophone
Sax Section 2 *	091-000-079	Saxophone
Saxophone + Organ *	093-000-034	Saxophone
Soft Sax Section Loose	082-000-044	Saxophone
Soft Sax Section Tight	082-000-045	Saxophone
Soprano Dream *	091-000-124	Saxophone
Soprano Sax *	090-000-057	Saxophone
Soprano Sax 2 *	091-000-123	Saxophone
Tenor Bostic	084-000-070	Saxophone
Tenor Sax	082-000-041	Saxophone
Tenor Sax Bostic *	090-000-076	Saxophone
Tenor Sax F	084-000-064	Saxophone
Tenor Sax F *	090-000-067	Saxophone
Tenor Sax Legato	093-000-077	Saxophone
Tenor Sax Live	093-000-091	Saxophone
Tenor Sax Sweet	084-000-065	Saxophone
Tenor Sax Sweet *	091-000-121	Saxophone
Tenor Sax W *	090-000-015	Saxophone
2 Violins	091-000-115	Strings
Attack Strings *	090-000-043	Strings
Bell Strings *	091-000-089	Strings
Bright Legato Strings	082-000-088	Strings
Bright Strings Velocity Attack	082-000-089	Strings
CD-Violin *	091-000-000	Strings
Cello *	090-000-123	Strings
Classical Large Strings	093-000-081	Strings
Classical Small Strings	093-000-096	Strings
Contrabass *	091-000-092	Strings
Fiddle *	091-000-067	Strings
GM041 Violin *	089-000-040	Strings
GM042 Viola *	089-000-041	Strings
GM043 Cello *	089-000-042	Strings
GM045 Tremolo Strings *	089-000-044	Strings
GM046 Pizzicato Strings *	089-000-045	Strings
GM049 Strings 1 *	089-000-048	Strings
GM050 Strings 2 *	089-000-049	Strings
GM051 Synth Str 1 *	089-000-050	Strings
GM052 Synth Str 2 *	089-000-051	Strings
GM111 Fiddle *	089-000-110	Strings
Gypsy Violin	093-000-092	Strings
Legato-Pizz	082-000-095	Strings
Legato-Tremolo	082-000-094	Strings
Marcato Strings	082-000-093	Strings
Oboe + Bassoon + Strings *	091-000-112	Strings
Pizzicato 1 *	090-000-050	Strings
Pizzicato 2 *	093-000-022	Strings
Pizzicato Strings	082-000-092	Strings
Soft Legato Strings	082-000-086	Strings
Soft Strings Velo Attack	082-000-087	Strings
Soft+Bright Legato Strings	082-000-090	Strings
Strings + Harp *	091-000-106	Strings



Category - Alphabetical

Strings + Horns	082-000-097	Strings
Strings + Pizzicato *	091-000-107	Strings
Strings 1 Soft *	090-000-006	Strings
Strings Attack *	090-000-007	Strings
Strings Mantovani *	091-000-102	Strings
Strings Sustain *	091-000-103	Strings
Strings Tremolo *	091-000-105	Strings
Strings Velocity Attack *	093-000-021	Strings
Strings Violins *	091-000-108	Strings
Strings Violins Attack *	091-000-109	Strings
Strings Vocal *	091-000-104	Strings
Synth Strings 1 *	091-000-024	Strings
Synth Strings 2 *	091-000-025	Strings
Tremolo Strings	082-000-091	Strings
Viola *	090-000-122	Strings
Violin + Strings *	091-000-110	Strings
Violin 1 *	090-000-008	Strings
Violin 2 *	090-000-101	Strings
Violin Solo *	091-000-116	Strings
Warm Strings Pad	082-000-096	Strings
5th Pulse Lead	083-000-056	Synth
5th Saw	091-000-043	Synth
5th Saw Lead	083-000-052	Synth
8 Voice Synth Horns	081-000-090	Synth
808 State Lead	083-000-053	Synth
Alfred's Filter Solo	083-000-049	Synth
Analogue Heaven	083-000-054	Synth
Analogue Sequence	083-000-068	Synth
Analogue Synth Brass	081-000-089	Synth
Analogy Pad	083-000-010	Synth
Angel *	090-000-066	Synth
Arail MO	081-000-077	Synth
Art of Choir	081-000-076	Synth
Atmosphere *	091-000-056	Synth
Attack Choir	081-000-078	Synth
Band Poly Lead	083-000-040	Synth
Basic Bend Lead	083-000-059	Synth
Bass + Lead *	091-000-044	Synth
Bassline Style Lead	083-000-035	Synth
Bell Choir	081-000-079	Synth
Bigger Than Life	083-000-041	Synth
Blippo Loop	083-000-092	Synth
Bowed Glass *	091-000-049	Synth
Brass Pad *	093-000-017	Synth
Bright Buzzer Poly	083-000-044	Synth
Bright Moving Pad	083-000-031	Synth
Bright Sweep Pad	083-000-017	Synth
Brightness *	091-000-057	Synth
Cascading	083-000-073	Synth
CD-Fairlight *	091-000-009	Synth
CD-Galaxy *	091-000-010	Synth
CD-Synth Brass *	091-000-004	Synth
CD-Theater *	091-000-013	Synth
Ceremonial Pad	083-000-018	Synth

Category - Alphabetical

Chaos	083-000-074	Synth
Charang *	091-000-041	Synth
Chase 4 Pad	083-000-023	Synth
Chiff *	091-000-040	Synth
Combo Loop	083-000-088	Synth
Cosmic *	090-000-039	Synth
Crystal *	091-000-055	Synth
Dance Sawteeth	083-000-066	Synth
Dance Stabs Lead	083-000-036	Synth
Dark Driver Arpeggio	083-000-094	Synth
Dark Driver Lead	083-000-033	Synth
Dark Pulsator	083-000-097	Synth
Dark Vox	081-000-074	Synth
Deep Mystery *	091-000-087	Synth
Dirty Sweep Pad	083-000-006	Synth
Dreamharp *	090-000-028	Synth
Dreaming *	090-000-041	Synth
Drum n Bass	083-000-055	Synth
Dry Fat Pulse Solo	083-000-058	Synth
Duck Trumpet	082-000-035	Synth
Dull Square Solo	083-000-046	Synth
Echo Drops *	091-000-059	Synth
Elektro Perc Lead	083-000-034	Synth
Fantasia *	091-000-045	Synth
Fat Analogue Lead	083-000-064	Synth
Fat Hit	081-000-083	Synth
Filter Brass *	093-000-014	Synth
Funky Chap Loop	083-000-091	Synth
Gangsta Whine	083-000-045	Synth
GG-Air Mallet *	091-000-020	Synth
GG-Fusion *	091-000-019	Synth
GG-Perc Echo *	091-000-021	Synth
Ghost Ship Pad	083-000-029	Synth
Ghost Wave Pad	083-000-012	Synth
Glass Menagerie	083-000-072	Synth
Glassy Pad	083-000-022	Synth
GM063 Synth Brass 1 *	089-000-062	Synth
GM064 Synth Brass 2 *	089-000-063	Synth
GM077 Blown Bottle *	089-000-076	Synth
GM081 Lead Square *	089-000-080	Synth
GM082 Sawtooth *	089-000-081	Synth
GM084 Chiff *	089-000-083	Synth
GM085 Charang *	089-000-084	Synth
GM087 5th Saw *	089-000-086	Synth
GM089 Fantasia *	089-000-088	Synth
GM090 Warm Pad *	089-000-089	Synth
GM091 Polysynth *	089-000-090	Synth
GM092 Space Vocal *	089-000-091	Synth
GM093 Bowed Glass *	089-000-092	Synth
GM094 Metal Pad *	089-000-093	Synth
GM095 Halo Pad *	089-000-094	Synth
GM096 Sweep Pad *	089-000-095	Synth
GM097 Ice Rain *	089-000-096	Synth
GM098 Soundtrack *	089-000-097	Synth

Category - Alphabetical

GM099 Crystal *	089-000-098	Synth
GM100 Atmosphere *	089-000-099	Synth
GM101 Brightness *	089-000-100	Synth
GM102 Goblins *	089-000-101	Synth
GM103 Echo Drops *	089-000-102	Synth
GM104 Star Theme *	089-000-103	Synth
GM109 Kalimba *	089-000-108	Synth
Goblins *	091-000-058	Synth
Halo Pad *	091-000-051	Synth
Heaven Choir	081-000-072	Synth
Heaven Panflute *	091-000-077	Synth
Hit Cluster	081-000-084	Synth
HP Synth Brass	081-000-091	Synth
Hybrid Brass Section	081-000-099	Synth
Hybrid Horn Section	082-000-085	Synth
Ice Rain *	091-000-053	Synth
In Need of Oil	083-000-077	Synth
Italo Hit	081-000-085	Synth
LoFi Sinus	072-000-092	Synth
Long Sweep Pad	083-000-014	Synth
Lost Souls Pad	083-000-027	Synth
Mega Pad	083-000-011	Synth
Metal Pad	083-000-011	Synth
Milky Way Pad	083-000-008	Synth
Modern Lead	083-000-069	Synth
Oberheim *	090-000-029	Synth
Oberhype Brass	081-000-092	Synth
OscSync Solo	083-000-071	Synth
Packman Loop	083-000-090	Synth
Paradise *	091-000-086	Synth
Perc Chime Arpeggio	083-000-095	Synth
Phaser Dance	083-000-070	Synth
Pitch EG Lead	083-000-063	Synth
Poly Slap	083-000-065	Synth
Polysynth *	090-000-051	Synth
Power Swell Pad	083-000-019	Synth
Pulse Lead	083-000-057	Synth
Pulsing Wave Pad	083-000-013	Synth
Punch Brass	081-000-094	Synth
Pypa Arpeggio	083-000-098	Synth
R2D2	083-000-078	Synth
Rave Synth Lead	083-000-037	Synth
Retro Pad	083-000-016	Synth
Reverse Choir	081-000-075	Synth
Rhythmic Pad	083-000-025	Synth
Rising Star Pad	083-000-030	Synth
RolandY *	090-000-027	Synth
S + H Worlds Pad	083-000-009	Synth
Saw Pad Sweep	083-000-003	Synth
Screamer Lead 1	083-000-061	Synth
Screamer Lead 2	083-000-062	Synth
Seq Brass *	093-000-015	Synth
Shamisen *	091-000-063	Synth
Shooting Stars	083-000-043	Synth

Category - Alphabetical

Slave Camp Pad	083-000-032	Synth
Soft Groove Pad	083-000-021	Synth
Soft Res Brass	081-000-095	Synth
Soft Super Saw Pad	083-000-004	Synth
Soft Sweeper Choir	081-000-080	Synth
Soft Synth Brass 1	081-000-093	Synth
Soft Synth Brass 2	081-000-098	Synth
Softly Pad	083-000-002	Synth
Solo Vox *	091-000-042	Synth
Soloing Lead	083-000-047	Synth
Soundtrack *	091-000-054	Synth
Space Vocal *	091-000-048	Synth
Spaced Choir	081-000-071	Synth
Special Bells Pad	081-000-069	Synth
Speech Sequencer	083-000-099	Synth
Square Lead	083-000-060	Synth
Star Theme *	091-000-060	Synth
Stardust Pad	083-000-020	Synth
Super Mini Lead	083-000-048	Synth
Super Synth Lead	083-000-038	Synth
Sweep Pad *	091-000-052	Synth
Sweeping Pad + Bells	083-000-001	Synth
Swoosh Pad	083-000-015	Synth
Syncerator	083-000-042	Synth
Synth Bass Ped *	093-000-002	Synth
Synth Brass 1	081-000-097	Synth
Synth Brass 1 *	090-000-031	Synth
Synth Brass 2 *	093-000-012	Synth
Synth Brass 3 *	093-000-013	Synth
Synth Brass Pad	081-000-096	Synth
Synth Guitar	082-000-022	Synth
Synth Strings	084-000-106	Synth
Tension	083-000-076	Synth
Theremin	083-000-050	Synth
Thin Air Pad	081-000-073	Synth
Tite Room Funk Loop	083-000-089	Synth
Trancefloor Lead	083-000-067	Synth
Tuba *	091-000-027	Synth
Twilight *	093-000-016	Synth
Urban Pad	083-000-026	Synth
Vangelis Pad	083-000-000	Synth
Velo Stabs	082-000-083	Synth
Vocalising Pad	083-000-007	Synth
Wannabe TB	083-000-051	Synth
Warm Pad *	091-000-046	Synth
Worlds Apart Pad	083-000-005	Synth
Worried Dave Pad	083-000-028	Synth
Theatre Organ + Vocal *	093-000-053	Theatre Organ
Digital Choir	081-000-070	Vocal
Duh Choir *	090-000-042	Vocal
DuhChoir	084-000-100	Vocal
GG-Synvocal *	091-000-018	Vocal
Girl Sustain *	090-000-102	Vocal
GM053 Choir Aahs *	089-000-052	Vocal

Category - Alphabetical

GM054 Voice Oohs *	089-000-053	Vocal
GM055 Synth Voice *	089-000-054	Vocal
GM086 Solo Vox *	089-000-085	Vocal
Jazz Vocal Baah *	090-000-088	Vocal
Jazz Vocal Bass *	090-000-092	Vocal
Jazz Vocal Dooh *	090-000-089	Vocal
Jazz Vocal Mixed *	090-000-090	Vocal
Jazz Vocal Mixed + Bass *	090-000-091	Vocal
Synth Voice *	090-000-125	Vocal
Vocal + Solo *	091-000-078	Vocal
Vocal 1 *	090-000-036	Vocal
Vocal 2 *	090-000-011	Vocal
Vocal Bells *	091-000-088	Vocal
Vocal Boys *	090-000-087	Vocal
Vocal Mixed *	090-000-085	Vocal
Vocal Mixed + Boys *	090-000-086	Vocal
Vocals Aah	093-000-082	Vocal
Vocals Aah Woman	093-000-083	Vocal
Vocals Ooh Woman	093-000-084	Vocal
Vocals Opera	093-000-085	Vocal
Bassoon	082-000-050	Woodwind
Bassoon *	091-000-029	Woodwind
Bottle *	091-000-032	Woodwind
Calliope *	091-000-039	Woodwind
CD-English Horn *	091-000-016	Woodwind
CD-Oboe *	091-000-015	Woodwind
CD-Whistle *	091-000-011	Woodwind
Clarinet 1 *	090-000-017	Woodwind
Clarinet 2 *	093-000-040	Woodwind
Clarinet Loose	082-000-048	Woodwind
Clarinet Swing	093-000-079	Woodwind
English Horn *	090-000-096	Woodwind
Flute	082-000-051	Woodwind
Flute	093-000-080	Woodwind
Flute Tremolo Fade	082-000-052	Woodwind
Flute Tremolo Switch	082-000-053	Woodwind
Flute Vibrato	082-000-054	Woodwind
GG-Panflute *	091-000-017	Woodwind
GG-Schalmei *	091-000-096	Woodwind
GM069 Oboe *	089-000-068	Woodwind
GM070 English Horn *	089-000-069	Woodwind
GM071 Bassoon *	089-000-070	Woodwind
GM072 Clarinet *	089-000-071	Woodwind
GM073 Piccolo *	089-000-072	Woodwind
GM074 Flute *	089-000-073	Woodwind
GM075 Recorder *	089-000-074	Woodwind
GM076 Pan Flute *	089-000-075	Woodwind
GM078 Shakuhachi *	089-000-077	Woodwind
GM079 Whistle *	089-000-078	Woodwind
GM080 Ocarina *	089-000-079	Woodwind
GM083 Calliope *	089-000-082	Woodwind
Jazz Flute 1 *	090-000-018	Woodwind
Jazz Flute 2 *	093-000-020	Woodwind
Oboe *	090-000-020	Woodwind

Category - Alphabetical

Ocarina *	091-000-036	Woodwind
Pan Pipe 1 (Pan Flute 1) *	090-000-019	Woodwind
Panflute 2 *	093-000-018	Woodwind
Piccolo *	091-000-030	Woodwind
Piccolo 1	082-000-055	Woodwind
Recorder *	091-000-031	Woodwind
Shakuhachi *	091-000-033	Woodwind
Shakuhachi Solo *	091-000-034	Woodwind
Sweet Clarinet *	093-000-019	Woodwind
Thin Clarinet	082-000-049	Woodwind
Whistle *	091-000-035	Woodwind